

Side Flange Modification for BMW E92 M3 / E60 M5 /

E63/64 M6 OS GIKEN Super Lock LSD or TCD

You need to modify side flanges for BMW E92 M3 Super Lock LSD or TCD installation.

Please re-use originally equipped longer side flange (BMW OEM Side Flange # 33 13 2 229 972). You do not need originally equipped shorter side flange for the installation. Please purchase 1 x BMW OEM Side Flange # 33 13 2 229 972 to replace with the shorter side flange.

You need to shorten 2 x BMW OEM Side Flange # 33 13 2 229 972. Both side flanges are needed to be shortened at 78.8mm from the origin of the measurement (Please refer to Picture 1 for details.).



Picture 1

- ※ Please be aware of potential risks and hazards when installing our products. We do not take any responsibility for any loss and/or injury occurred when our products are modified, re-used and/or ill-fitted. We do not take any responsibility for any loss and/or injury that resulted from the failure in following instructions given on this sheet.
- ※ All information on this manual is collected from BMW E92 M3 sold in Japan and it may not be applicable to the vehicles sold in your country.
- ※ Specifications may be changed without notice.